


محطة سريان الفاح لى صوت SH 0528 - نى الف م س ر ل ا ة روص



 Ø	H	B	C	DN	Model#
100	105	48,5	110	50	0528 06
160	135	49	174	50	

DN	d	D	b	k	d ₁	f	d ₂ x n
50	50	165	20	125	102	3	18 x 4